

TROUBLESHOOTING

PROBLEM	CAUSE	SOLUTION
The sanitiser isn't working.	Switch not pressed.	Press the switch to "ON".
	Plug not inserted.	Insert the plug into the socket.
	No current.	Check the power supply line.
The sanitiser is on but does not dispense the sanitising solution.	The system circuit is empty.	Press the lever and wait for the internal machine circuit to fill up to be available for use with the dispensing nozzle.
	The tank is empty.	Fill the tank.
	Pump fault.	Contact an authorised service centre.